

501 Waterford, C Wing, C.D.Barfiwala Marg(Juhu Lane), Andheri(W), Mumbai 400 058. INDIA

Email tcmktg@sarex.com URLwww.sarex.com

PRODUCT LITERATURE

REDUCON-ACD (CONC)

Product Information

Reducon-ACD (Conc) is a reduction clearing agent available in powder form. Reducon-ACD (Conc) removes unfixed disperse dyes in acidic medium from polyester and its blends with polyacrylonitrile. It is applied in cooling dyebath of acidic medium. It is water soluble thus make easy dosing process.

Key Features & Benefits

Key Features Benefits

Works under acidic pH Alkalifying, fresh bath and

reacidifying is not require

Dyeing followed by reduction Saves time, energy, water and

clearing in the same dve bath reduces effluent load

General Characteristics

Physical appearance : White to off white powder

Ionic nature : Nonionic
pH of 1% solution : 11 +/- 2

Miscibility : Soluble with water

Compatibility : Compatible with anionic, cationic and nonionic products

Stability : Stable to dilute acids and dilute alkalies

Application

It is highly effective in a cooling acid dye bath, the pH of the bath should be 3.5-4.5

After dyeing, treat the dyed substrate at 70-80 deg.C for 10-20 min. followed by rinsing.

SUGGESTED RECIPE - Light to Medium shade

Substrate Dosage*

Polyester 0.5-1% (owf)

501 Waterford, C Wing, C.D.Barfiwala Marg(Juhu Lane), Andheri(W), Mumbai 400 058. INDIA

Email tcmktg@sarex.com URLwww.sarex.com

PRODUCT LITERATURE

REDUCON-ACD (CONC)

Polyester/Spandex 1-2% (owf)

Saragen-SO 0.3-0.5 g/l (Optional) OR

Saragen-DAM 1.0-2.0% (Optional)

Addition of dispersing agents (Saragen-SO, Saragen-DAM) improves removal of dye in case of polyester/spandex.

Dosages of diluted product to be calculated on the basis of solid content.

Dosages to be taken depending on the depth of shade.

Note: For Dark shade

Drain the dye bath and then add 1-2% owf Reducon-ACD (Conc) + 1% Saragen-SO at pH 3.5-4.5

Instructions For Dilution

Procedure to prepare 25% diluted product of 100% Reducon-ACD (Conc)

- Take 25 parts of Reducon-ACD (Conc)
- To this, add 75 parts of DM water.
- Stir at 200-300 rpm for 40-45 min. till Reducon-ACD (Conc) is completely dissolved.

Preservation:

It is recommended to add 0.1% Bronopol (2-Bromo,2-nitropropane, 1,3-diol) or Methyl Paraben (methyl para hydroxy benzoate) as an antimicrobial agent to avoid fungal / microbial growth.

Precautions

Storage

: Store in cool, ventilated shed away from heat and direct sunlight. Storage temperature should not exceed 35 deg C. Close lids firmly to avoid contact with air and moisture.



501 Waterford, C Wing, C.D.Barfiwala Marg(Juhu Lane), Andheri(W),Mumbai 400 058. INDIA

Email tcmktg@sarex.com URLwww.sarex.com

PRODUCT LITERATURE REDUCON-ACD (CONC)

Shelf Life	: 9 months from the date of manufacturing, if stored under controlled conditions.

This is a computer generated report. Hence not signed.