

501 Waterford, C Wing, C.D.Barfiwala Marg(Juhu Lane), Andheri(W),Mumbai 400 058. INDIA

Phone +91 22 42184218 **Fax** +91 22 42184350

Email :tcmktg@sarex.com URL www.sarex.com

PRODUCT LITERATURE

SARASTABIL-CONC

Product Information

Sarastabil-CONC is a powder form concentrated organic peroxide stabilizer for combined scouring and bleaching as well as peroxide bleaching of cotton and polyester/ cellulosic blends by exhaust as well as continuous process. Sarastabil-CONC is having preferential chelating action on iron and hence prevents catalytic damage and pin hole marks in cotton.

Sarastabil-CONC is silicate free and magnesium free and does not lead to any deposits on substrate or machine.

Key Features & Benefits

Key Features	Benefits
Organic stabilizer	 No silicate deposits on fabrics or machine so feel of fabric is not affected
Concentrated	Lower dosage, economical and readily soluble
Good sequestering action on iron	Prevents damage to cotton and pin-hole marks

General Characteristics

Physical appearance : Off white to white powder Ionic nature : Anionic pH of 1% solution : 6 +/- 1 Miscibility : Soluble in water Compatibility : Compatible with anionic and nonionic products Stability : Stable to dilute acids, alkali, peroxide particularly concentrations used in dosing on CBR

Application

- 1. Exhaust application
 - 0.5% Celldet-R



501 Waterford, C Wing, C.D.Barfiwala Marg(Juhu Lane), Andheri(W),Mumbai 400 058. INDIA

Phone +91 22 42184218 **Fax** +91 22 42184350

Email :tcmktg@sarex.com URL www.sarex.com

PRODUCT LITERATURE

SARASTABIL-CONC

	2%	Caustic flakes		
	18	Soda ash		
	3-8%	Hydrogen Peroxide (50%)		
	0.5-1%	Saraquest-2UD (Optional)		
	0.02-0.04%	Sarastabil-CONC		
	Treat at 98	deg.C for 45-90 min, or 110 deg.C for 15-45 min,		
2.	Pad applicat	ion		

•	raa ar	pricac	1011
	40-50	ml/kg	Hydrogen peroxide (50%)
	15-18	gm/kg	Caustic soda flakes
	5-6	ml/kg	Envicare-CP
	3-4	gm/kg	Sarastabil-CONC
	0.5-1	ml/kg	Saraquest-W
	Steam	at 98	deg.C for 15-20 min.

Instructions For Dilution

Procedure to prepare 25% Sarastabil-CONC

- Take 75 parts of DM water
- To this, gradually add 25 parts Sarastabil-CONC with constant stirring
- Stir at 300-400 rpm using normal/turbo stirrer for 30-40 min. till clear liquid is obtained OR powder is completely dissolved.

Preservation: It is recommended to add 0.1% Bronopol (2-Bromo,2-nitropropane, 1,3-diol) or Methyl Paraben (methyl para hydroxy benzoate) as an antimicrobial agent to avoid fungal / microbial growth.

Note: Our recommendation is to make 1:4 dilution of Sarastabil-CONC for dosing on continuous range.

It is advisable to utilize the diluted product within 2 months. Stir well before use.

Precautions

Storage : Store in cool, ventilated shed away from heat and direct sunlight. Storage temperature should not exceed 35 deg C. Close lids firmly to avoid contact with air and moisture.



501 Waterford, C Wing, C.D.Barfiwala Marg(Juhu Lane), Andheri(W),Mumbai 400 058. INDIA

Phone +91 22 42184218 **Fax** +91 22 42184350

Email :tcmktg@sarex.com URL www.sarex.com

PRODUCT LITERATURE

SARASTABIL-CONC

Shelf Life

: 9 months from the date of manufacturing, if stored under controlled conditions.

[The above information is given in good faith and is without warranty] [Prod.Code :L008475 | Last Upd. On : 19/08/20] [MOLL]

This is a computer generated report. Hence not signed.