

Email tcmktg@sarex.com URLwww.sarex.com

# PRODUCT LITERATURE

## **ZOROFAST-FMD**

### Product Information

Zorofast-FMD is a speciality finishing agent to improve dry and wet rub fastness of all types of dyed and printed cotton and their blends. It is compatible with certain cationic and nonionic silicone finishing agents. It can be applied by both dry-on-wet and wet-on-wet application. Zorofast-FMD comply with the eco parameters.

## Key Features & Benefits

Key Features Benefits

Excellent improvement in wet Improves by 1.5-2.0 units on direct, reactive,

rub fastness sulphur, indigo and pigment dyed fabrics

Does not contain harmful solvents Comply with the eco parameters

#### General Characteristics

Physical appearance : Yellow to yellow brown liquid Ionic nature : Weakly cationic to Amphoteric

pH of 1% solution : 4 +/-1

Miscibility : Miscible with water

Compatibility : Compatible with cationic and non ionic products

Stability : Stable to dilute acids and unstable to dilute alkalies

### **Application**

Padding method:

Step wise procedure for preparing Zorofast-FMD solution

- Take required quantity of Zorofast-FMD (30 g/l)
- To this, gradually add water (pH 5.8-6.2) and make the total volume
- Mix well to get uniform solution



Email tcmktg@sarex.com URLwww.sarex.com

# PRODUCT LITERATURE

## **ZOROFAST-FMD**

- Solution of 30 g/l Zorofast-FMD will appear Colourless to straw white liquid with pH 3.7-4.2

#### Padding Application:

Pad -> Dry at 130-160 deg.C

Exhaust method - in Garment:

Step wise procedure for preparing Zorofast-FMD solution

- Take required quantity of (3-5% on weight of garment) and mix it uniformly
- To this, gradually add water (pH 5.8-6.2) and make the total volume
- Mix well to get uniform solution
- Solution of 3-5% Zorofast-FMD will appear Colourless to straw white liquid with pH 3.7-4.2

#### Exhaust process:

\_\_\_\_\_

40deg.C, 20-30 min (with intermittent stirring)
Dry --> Curing @ 150-160 deg.C, 2-3 min

#### Note:

- 1. Fabric to be treated should be free from anionic components.
- 2. pH of the fabric should be neutral.
- 3. Absorbency of fabric should be instant. To improve absorbency of all over printed fabric (reactive/pigment), 0.2-0.5 g/l Celldet-R (wetting agent) is to be added in the finishing bath.
- 4. For garments, it is essential to cure at 150 deg.C after exhaustion
- 5. Zorofast-FMD has limited durability to washing

# **Sarex Chemicals**

(A Divn. Of Saraf Chemicals Pvt. Ltd.)

501 Waterford, C Wing, C.D.Barfiwala Marg(Juhu Lane), Andheri(W),Mumbai 400 058. INDIA

Email tcmktg@sarex.com URLwww.sarex.com

# **PRODUCT LITERATURE**

## **ZOROFAST-FMD**

#### Special Instructions:

- If the water pH>6.2, adjust it to pH 5.8-6.2 and then use.
- 30 g/l Zorofast-FMD will appear Colourless to straw white.
- Avoid using hard water.
- Prepare the solution at room temperature (approx.30 deg.C)
- The prepared solution to be kept under constant stirring and to be used immediately
- Do not keep Zorofast-FMD stock solution standing.
- Ensure that the padding bath pH is 3.7-4.2 throughout the process.
- Pre-lab trials are recommended with other finishing agents.
- On standing the product tends to turn darker.

### Precautions

Storage : Store in cool, ventilated shed away from heat and direct

sunlight. Storage temperature should not exceed 35 deg C. Close lids firmly to avoid contact with air and moisture.

Shelf Life : 9 months from the date of manufacturing, if stored under

controlled conditions.

[The above information is given in good faith and is without warranty] [ Prod.Code :L009343 | Last Upd. On : 11/06/25 ] [PP]

This is a computer generated report. Hence not signed.